


- **How do I upgrade the firmware on my router?**

**Step 1:** Download the latest firmware for your DIR Series router from <http://sg.mydlink.com/support> or your local D-Link support website.

**Step 2:** Once you've downloaded the firmware, open a web browser such as Internet browser and enter **http://dlinkrouter**, **http://dlinkrouter.local**, or **http://192.168.0.1** into the address bar.



**Step 3:** The default username is Admin. Enter the password for your Admin account. If you have not changed the password from its default, the password field should be left blank. Click **Login**.

A screenshot of the D-Link router's login interface. At the top is an orange banner with the "D-Link" logo. Below this is a "LOGIN" section with a light gray background. It contains the text "Login to the router :", followed by "User Name : Admin" and "Password :". There are input fields for the username and password, and a "Login" button. At the bottom of the page is a dark gray banner with the word "WIRELESS" in white.

**Step 4:** Click on the Tools tab on the top and then click on Firmware from the menu on the left-hand side. Under Firmware Upgrade click on the **Browse** button and locate the .bin file you downloaded in Step 1. Highlight the file by clicking on it once and then click **Open**.

**Step 5:** Click on **Upgrade** to upgrade firmware. It may take up to 30 seconds for the upgrade to complete. When the upgrade is complete, a confirmation window will appear, click **Continue** when it appears. The firmware is now upgraded.

The screenshot displays the D-Link router's web management interface. At the top, there are navigation tabs: SETUP, ADVANCED, **TOOLS** (selected), STATUS, and SUPPORT. On the left side, a vertical menu lists various settings: ADMIN, TIME, SYSLOG, EMAIL SETTINGS, SYSTEM, **FIRMWARE** (selected), DYNAMIC DNS, SYSTEM CHECK, and SCHEDULES. The main content area is divided into several sections. The top section, titled 'FIRMWARE UPDATE', contains instructions on how to upgrade the firmware and language pack. Below this is the 'FIRMWARE INFORMATION' section, which shows the current firmware version as 1.01 and the current time as 10/04/2013 18:55:00. It also includes a 'Check Online Now for Latest Firmware Version' button. The 'FIRMWARE UPGRADE' section provides a note that some upgrades reset configuration options and includes an 'Upload' button for the firmware file. At the bottom, the 'LANGUAGE PACK UPGRADE' section is partially visible. On the right side, a 'Helpful Hints...' sidebar provides additional information about firmware updates, including a link to 'Check Now' and a 'More...' link.