


D-Link® Technical Support Setup Procedure

How to Change the DCS-5020L Login Password

Step 1: Run the CD Set-Up that came with the DCS-5020L. On the Set-Up Wizard screen click on **Set up your Cloud Camera** button.




Step 2: Click on **Start** button on the next window that comes up.



Step 3: Under End User License Agreement, put a check mark on **I accept these Terms and Conditions**, then click on **Next** button.



Step 4: Plug the included Ethernet cable into the port on the back of the Cloud Camera, then Click on **Next** button to continue.



Step 5: Plug the other end of the cable into the LAN port on your router. Click **Next** button to continue.

mydlink DCS-5020L Setup Wizard

Connect your Cloud Camera

Connect 1 Network 2 Enable 3

Please follow these instructions to connect your Cloud camera.

1. Cloud Camera
2. Router
3. Power adapter
4. LED

[Click here to see a basic overview of how your devices connect together.](#)

Plug the other end of the cable into a LAN port on your router.

Back Next

Troubleshooting Downloads About Exit

Step 6: Connect the power adapter to the power connector on the back of the DCS-5020L, then plug the adapter into a power outlet. Click **Next** button.

mydlink DCS-5020L Setup Wizard

Connect your Cloud Camera

Connect 1 Network 2 Enable 3

Please follow these instructions to connect your Cloud camera.

1. Cloud Camera
2. Router
3. Power adapter
4. LED

[Click here to see a basic overview of how your devices connect together.](#)

Connect the power adapter to the power connector on the back of the DCS-5020L, then plug the adapter into a power outlet.

Back Next

Troubleshooting Downloads About Exit

Step 7: The LED on the cloud camera will turn solid green when it is ready, Click **Next** button to proceed.

mydlink DCS-5020L Setup Wizard


Connect your Cloud Camera

Connect 1 Network 2 Enable 3

Please follow these instructions to connect your Cloud camera.

1. Cloud Camera
2. Router
3. Power adapter
- ▶ 4. LED

[Click here to see a basic overview of how your devices connect together.](#)



The LED on the Cloud Camera will turn solid green when it is ready.

[*What should I do if the LED stays red?](#)

Back Next

Troubleshooting Downloads About Exit

Step 8: Click on the button **Yes** if the LED at the back of your camera is lit solid green.

Is the LED on the Cloud Camera lit solid green ?

Yes No

Step 9: You will now see the camera device information with its corresponding IP Settings and MAC Address. Create a password for your camera then, Click on the **Next** button.

mydlink DCS-5020L Setup Wizard

Select your Cloud Camera

Connect 1 Network 2 Enable 3

Cloud Camera	MAC ID	IP address	Connection
DCS-5020L	28:10:7B:09:77:66	192.168.0.105	DHCP

↻ Searching Cloud Cameras...

Registered with mydlink Not registered Wired Wireless

[Can't find your Cloud Camera in the list ?](#)

Please enter a password to secure your camera.

Admin account: admin

Password:

Confirm password:

Troubleshooting Downloads About Exit

Step 10: Open up a browser and on the address bar type in the IP address of the camera, then Login page of the camera comes up. Type **"admin"** for username and type your password for your camera. Then click on **Log In** button.

Windows Security


The server 192.168.0.105 at DCS-5020L requires a username and password.

Warning: This server is requesting that your username and password be sent in an insecure manner (basic authentication without a secure connection).

admin

Remember my credentials

Step 11: Click on **MAINTENANCE** Tab then, Click on **Admin** on the left hand side. Under the **ADMIN** page, Type in the Old Password, New Password and Retype the New password. Click on **Apply** to save the settings.

Product: DCS-5020L		Firmware version: 1.01				
						
DCS-5020L //		LIVE VIDEO	SETUP	MAINTENANCE	STATUS	HELP
Admin	ADMIN					Helpful Hints..
System	Here you can change the administrator's password and configure the server setting for your camera. You can also add, modify and/or delete the user account(s).					For security reasons, it is recommended that you change the Password for the Administrator accounts. Be sure to write down the new Login Names and Passwords to avoid having to reset the camera in the event that they are forgotten.
Firmware Upgrade	ADMIN PASSWORD SETTING					
Logout	Old Password	<input type="password"/>	New Password	<input type="password"/>	Retype Password	
		<input type="button" value="Apply"/>	<input type="button" value="Cancel"/>			