


Step 1: Unscrew the camera from the base

Step 2: On the bottom of the base, press in the 2 clips to remove the center piece of the base



Step 3: Screw the base into your desired wall or ceiling



Step 4: Re-attach the center cover



Step 5: Screw the camera back onto the base and adjust as needed.

