



How to change Wireless Network Name OR SSID on DIR-895L?


Step 1: Open an Internet browser (such as Internet Explorer) and enter <http://dlinkrouter/>, <http://dlinkrouter.local> or <http://192.168.0.1> into the address bar.



Step 2: Enter your login information. If you have not changed the default settings, the password field should be left blank. Click **Login**.



Step 3: Click the **Settings** tab at the top of the page and then click **Wireless** from the menu list.



Step 4: Select **Disabled** for **Smart Connect**.

Smart Connect



Step 5:

- a) **2.4Ghz:** Enter a **Wireless Network name** beside **Wi-Fi (SSID)**.
- b) **Primary 5Ghz:** Enter a **Wireless Network name** beside **Wi-Fi (SSID)**.
- c) **Secondary 5Ghz:** Enter a **Wireless Network name** beside **Wi-Fi (SSID)**

2.4GHz

Status: ☒ Enabled

Wi-Fi Name (SSID):

Password:

[Advanced Settings...](#)

Primary 5GHz

Status: ☒ Enabled

Wi-Fi Name (SSID):

Password:

[Advanced Settings...](#)

Secondary 5GHz

Status: ☒ Enabled

Wi-Fi Name (SSID):

Password:

[Advanced Settings...](#)

Step 6: Click on **Save**

Settings >> Wireless

[Guest Zone](#)

--- END ---