How to perform firmware upgrade of the router?

Step 1: Open an Internet browser (such as Internet Explorer)

Enter http://dlinkrouter, http://dlinkrouter.local or http://**192.168.0.1** into the address bar.



Step 2: Enter your login information. If you have not changed the default settings, the username is admin and the password field should be left blank.

Click **Sign in**.

Step 3: Click **System** tab at the top of the page to launch the System Management menu.



Step 4: Click on **Firmware Upgrade** and select Browse to locate the image file from folder stored.



Step 5: Click **Start Update** to begin the update process.



Update will take about 120 ~ 240 sec. (upto 2 min)

--- END ---