

**D-Link®**

WIRELESS N 300 ADSL2+ MODEM ROUTER  
DSL-2750E

**คู่มือการติดตั้ง**

A large, light gray, stylized watermark of the D-Link logo is positioned diagonally across the lower half of the page, behind the text.

# **D-Link<sup>®</sup>** Technical Support Setup Procedure

---

FAQ : Quick Installation for DSL-2750E

Release date : 1/04/2013

Model Support : DSL-2750E

H/W: T1


S/W:1.xx

# D-Link<sup>®</sup> Technical Support Setup Procedure

## WIRELESS N 300 ADSL2+ Modem Router DSL-2750E

### ขั้นตอนที่ 1 : การเชื่อมต่ออุปกรณ์


- 1.1 นำสายโทรศัพท์ที่ต่อจากผนัง เชื่อมต่อเข้ากับ DSL-2750E โดยตรง หรือ
- 1.2 หากต้องการเชื่อมต่อกับ Splitter เพื่อให้สามารถใช้งานโทรศัพท์ได้ตามปกติ และสามารถใช้งานอินเทอร์เน็ตได้พร้อม ๆ กัน ให้นำสายโทรศัพท์ที่ต่อจากผนังต่อเข้าพอร์ต Line บนอุปกรณ์ Splitter
- 1.3 จากช่อง Phone บน Splitter ให้เอาสายโทรศัพท์จากจุดนี้ไปยังหัวโทรศัพท์บ้าน
- 1.4 จากช่อง Modem บน Splitter ให้เอาสายโทรศัพท์จากจุดนี้ไปเข้าที่ตัว DSL-2750E
- 1.5 ให้นำสาย LAN (CAT5E : RJ45) จากพอร์ต LAN ใด ๆ ก็ได้ บน DSL-2750E ต่อเข้ากับพอร์ต LAN บนเครื่องคอมพิวเตอร์ของคุณ



ขั้นตอนที่ 2 : ทำการ Log In เข้าไปที่อุปกรณ์ Router

2.1 เปิด Web Browser (Internet Explorer , Firefox , Google Chrome) และใส่ค่า

<http://192.168.1.1> ที่ Address Bar ดังรูป



2.2 หลังจากนั้น จะพบหน้า Login โดยค่าแรกเริ่มจากโรงงาน คือ

Username : admin

Password : admin

หลังจากนั้น ใส่ค่า Username และ Password เรียบร้อยแล้ว ให้ทำการกดปุ่ม Login

**LOGIN**

Input username and password


Username : admin default username : admin

Password : ..... default password : admin

☐ Remember my login info. on this computer


Login

2.3 ในกรณีที่ใส่ Username หรือ Password ผิด หน้าจอจะขึ้นหน้าจอตามรูปด้านล่าง ให้ทำการใส่ค่า Username และ Password ให้ถูกต้องอีกครั้ง



**ขั้นตอนที่ 3 :** หลังจากที่ได้ใส่ Username และ Password ถูกต้องแล้ว จะสามารถเข้าไปยังหน้า Setup Wizard เพื่อติดตั้งค่าอุปกรณ์

3.1 เมื่อกดที่ปุ่ม Setup Wizard จะถูกนำเข้ายังหน้าถัดไป เพื่อแสดงขั้นตอนที่จะติดตั้ง



3.2 กดปุ่ม Next เพื่อไปยังขั้นตอนถัดไป จะพบว่า หน้าจอจะแสดงให้ตั้งค่า Time and Date ให้เลือกค่าต่าง ๆ ดังรูปด้านล่าง แล้วกดปุ่ม Next

**STEP 1: SET TIME AND DATE** 1 2 3 4 5

With the time configuration function, you can configure, update, and maintain the correct time of the internal system clock. In this page, you can set the time zone that you are in and set the network time protocol (NTP) server. You can also configure daylight saving to automatically adjust the time if necessary.

**TIME SETTING**

☒ Automatically synchronize with Internet time server

Primary NTP time server: ntp1.dlink.com

Secondary NTP time server: ntp.dlink.com.tw

Manual setup time: 2012 Year 05 Mon 23 Day 00 Hour 06 Min 26 Sec

**TIME CONFIGURATION**

Time Zone: (GMT+07:00) Bangkok, Hanoi, Jakarta

☒ Automatically adjust clock for daylight saving changes

Daylight Saving Start: 2000 Year 04 Mon 01 Day 02 Hour 00 Min 00 Sec

Daylight Saving End: 2000 Year 09 Mon 01 Day 02 Hour 00 Min 00 Sec

Back Next Cancel

3.3 หน้าถัดมาจะเข้าสู่การติดตั้ง PPPoE ให้เลือกประเทศที่ใช้งาน ซึ่งก็คือ Thailand (ประเทศไทย) หลังจากนั้น ในช่อง Internet Service Provider ให้เลือกผู้ให้บริการที่เราใช้งานอยู่ หลังจากเลือกแล้ว Router จะเลือกค่า VPI และ VCI ที่ถูกต้องให้กับเราเอง

Protocol : ให้เลือกเป็น PPPoE

หลังจากนั้นให้ใส่ค่า Username และ Password ที่ได้มาจากผู้ให้บริการ ลงไปในส่วนนี้ โดย Password ต้องใส่ 2 ครั้ง (ที่ช่อง Password และ Confirm Password) แล้วกดปุ่ม Next ในตัวอย่างนี้ เลือกใช้ TRUE แล้วใส่ Username : example@truehisp และ Password : password เป็นต้น

The screenshot displays the 'STEP 2: SETUP INTERNET CONNECTION' screen of the D-Link DSL-2750E web interface. The interface is divided into two main sections. The top section, titled 'STEP 2: SETUP INTERNET CONNECTION', contains a list of configuration options: 'country' (Thailand), 'ISP' (TRUE (Huawei)), 'Protocol' (PPPoE), 'Encapsulation Mode' (LLC), 'VPI' (0), and 'VCI' (100). A 'Search Available PVC' button is also present. The bottom section, titled 'PPPOE PPPoA', contains a text box for the user name and password, with a note that the information is case-sensitive. The 'Username' field is filled with 'example@truehisp', and the 'Password' and 'Confirm Password' fields are filled with 'password'. At the bottom of the form are 'Back', 'Next', and 'Cancel' buttons.

**STEP 2: SETUP INTERNET CONNECTION** . 3 . 4 . 5

Please select your ISP (Internet Service Provider) from the list below.

country : Thailand

ISP : TRUE (Huawei)

Protocol : PPPoE

Encapsulation Mode: LLC

VPI : 0 (0-255)

VCI : 100 (32-65535)

Search Available PVC : Scan

**PPPOE PPPoA**

Please enter the user name and password provided by your Internet service provider (ISP). Note that the information is case-sensitive. Click "Next" to continue.

Username : example@truehisp

Password : password

Confirm Password : password

Back Next Cancel

### 3.4 ขั้นตอนถัดมา จะเป็นการติดตั้ง Wireless (WIFI) หรืออุปกรณ์ไร้สาย

3.4.1 ให้เปิดการใช้งาน โดยเช็คที่ช่อง Enabled Your Wireless Network

3.4.2 เปลี่ยนค่า SSID (เปรียบเสมือน ชื่อของเครือข่าย ไร้สายของคุณ)

โดยสามารถตั้งชื่อได้ตามความต้องการ

3.4.3 ถ้าไม่ต้องการตั้งค่าระบบความปลอดภัยให้เลือก None

3.4.4 ถ้ามีความประสงค์ในการตั้งค่าความปลอดภัยของระบบเครือข่ายไร้สาย

โดยสามารถเลือกได้ทั้งระบบความปลอดภัยตั้งแต่ระดับต่ำสุด (WEP) ไปจนถึงสูงสุด (WPA2)

ในตัวอย่างนี้เลือก WPA2 โดย WPA2 Pre-Shared Key เป็น 12345678 เป็นต้น

เมื่อตั้งค่าต่าง ๆ เรียบร้อยแล้ว ให้กดปุ่ม Next เพื่อไปยังขั้นตอนต่อไป

**STEP 3: CONFIGURE WIRELESS NETWORK** 4 5

The wireless network is enabled by default. You can deselect it to disable it and click "Next" to skip the configuration of wireless network.

**Enable Your Wireless Network :** ☒

For security concerns, it is highly recommended to change the pre-configured network name. Please set a name for your wireless network that can be easily recognized by wireless clients.

**Wireless Network Name (SSID) :** D-Link

If you select "Visible", the SSID of your wireless network can be found by wireless clients. If you select "Invisible", your wireless network is hidden and users need to manually enter the SSID in order to connect to your wireless network.

**Visibility Status :** ☒ Visible ☐ Invisible

In order to protect your network from hackers and unauthorized users, you are highly recommended to select one of the following wireless network security settings.

None	Security Level		Best
<input type="radio"/> None	<input type="radio"/> WEP	<input type="radio"/> WPA-PSK	<input checked="" type="radio"/> WPA2-PSK

**Security Mode:** WPA2-PSK  
Select this option if your wireless adapters support WPA2-PSK.

Please enter your wireless security key:

**WPA2 Pre-Shared Key :**

(8-63 characters, such as a~z, A~Z, or 0~9, i.e. "%Fortress123&")

**Note:** Please enter the same key on your wireless clients to enable proper wireless connection.



**ขั้นตอนที่ 4 :** หน้าจอสำหรับการเปลี่ยนแปลงรหัสผ่าน (Password) ของ admin

4.1 ในกรณีที่ไม่มีความประสงค์ในการเปลี่ยนแปลง Password ให้กดปุ่ม Skip

4.2 ถ้าต้องการเปลี่ยนแปลงให้ดำเนินการต่าง ๆ ดังนี้

Current Password : ใส่ Password ปัจจุบันที่ใช้งานอยู่ (โดยค่าจากโรงงานเป็น admin)

New Password : ใส่ Password ที่ต้องการ

Confirm Password : ใส่ Password ใหม่ที่ต้องการอีกครั้ง (ตรงกับช่อง New Password) หลังจากนั้นกดปุ่ม Next เพื่อไปยังขั้นตอนต่อไป (รายละเอียดดังรูปด้านล่าง)

**D-Link**

**STEP 4: ACCOUNT PASSWORD** 5

Use the fields below to change or create passwords. Note: Password cannot contain a space.

**ACCOUNT PASSWORD**

Username:

Current Password:  default password : admin

New Password:

Confirm Password:

**BROADBAND**


ขั้นตอนที่ 5 : หน้าจอจะแสดงการตั้งค่าทั้งหมดที่ได้ตั้งค่าไว้ ถ้าถูกต้องแล้ว ให้คลิกปุ่ม Apply เพื่อให้การตั้งค่ามีผล

The following shows a detailed summary of your settings. Please print this page out or write the information on a piece of paper, and save it, so you can correctly configure the settings on your wireless client adapters later based on the information in this page.

Time Settings :	enable
NTP Server 1 :	ntp1.dlink.com
NTP Server 2 :	ntp.dlink.com.tw
Time :	not set!
Time Zone :	THA
Daylight Saving Time :	enable
Daylight start :	2000-04-01T02:00:00
Daylight end :	2000-09-01T02:00:00
wan_type :	DSL
VPI / VCI :	0/100
Protocol :	PPPoE
Connection Type :	LLC
Username :	example@truehisp
Password :	password
Wireless Network Name (SSID) :	D-Link
Visibility Status :	visible
Encryption :	WPA2-PSK
Pre-Shared Key :	12345678
WEP Key :	not set!
New password:	admin123

Back Apply Cancel

ขั้นตอนที่ 6 : หลังจากนั้น กรุณารอสักครู่โดยเราเตอร์จะทำการรีบูต หลังจากเสร็จขั้นตอนนี้เป็นอันเสร็จวิธีการตั้งค่า



Quick Installation for DSL-2750E

**D-Link**

## ฝ่ายสนับสนุนทางด้านเทคนิค

Call Center หมายเลขโทรศัพท์ 02-6617997

ภาษาไทย : จันทร์ ถึง ศุกร์ เวลา 9.00 น. – 18.00 น.

Thai : Mon – Fri : Time 9.00 – 18.00.

ภาษาอังกฤษ : เสาร์ , อาทิตย์ , วันหยุดนักษัตฤกษ์ และ วันธรรมดา หลัง 18.00 น.

English : Sat – Sun , Public Holiday and after 18.00 weekday.

Website : [www.dlink.co.th](http://www.dlink.co.th)

Email: [support@dlink.com.sg](mailto:support@dlink.com.sg)

Facebook : <http://www.facebook.com/DLinkThailandFans>

## **Nationwide D-Link Service Centres**

### **Chiang Mai Branch**

2/1 Moo 3, Chiang Mai-Lampang Road  
Tumchon Chang Ruesak, Amphoe Muang Chiang Mai  
Changwat Chiang Mai 50300,  
Thailand

Tel : +66 (0) 5340-9482-6  
Fax : +66 (0) 5340-9486  
Operating hours:  
Mondays till Friday  
9am to 6pm

### **Phitsanulok Branch**

117/7 Praongdam Road  
Tumchon Nai Muang,  
Amphoe Muang Phitsanulok  
Changwat Phitsanulok 65000, Thailand

Tel : +66 (0) 5521-2323-5  
Fax : +66 (0) 5521-2326  
Operating hours:  
Mondays till Friday  
9am to 6pm

### **Cham Issara Tower II**

3rd Floor, Cham Issara Tower II  
2922/138 New Perchburi Road  
Khwang Bangkok, Khet Huay-Kwang,  
Bangkok 10320, Thailand

Tel : +66 (0) 2308-2040  
Fax : +66 (0) 2308-2024  
Call Center : +66 (0) 2716-6669  
Operating hours:  
Mondays till Friday  
9am to 6pm

### **Pantip Plaza Branch**

4th Fl, Pantip Plaza 604/3 Petchburi Road Room  
439-440  
Kwang Thanon Petchburi, Khet Ratchathewi  
Bangkok 10400, Thailand

Tel : +66 (0) 2656 6037  
Fax : +66 (0) 2656 6054  
Operating hours:  
Mondays till Sunday  
10am to 7pm

### **Rayong Branch**

217/24 Sukhumvit Road  
Tumchon Noen Phra,  
Amphoe Muang Rayong  
Changwat Rayong 21000, Thailand

Tel : +66 (0) 3880-0631-3  
Fax : +66 (0) 3880-0634  
Operating hours:  
Mondays till Sunday  
9am to 6pm

### **Surat Thani Branch**

412/8 Talat Mai Road  
Tumchon Talat,  
Amphoe Muang Surat Thani  
Changwat Surat Thani 84000, Thailand

Tel : +66 (0) 7721-7907-10  
Fax : +66 (0) 7721-7910  
Operating hours:  
Mondays till Friday  
9am to 6pm

### **Phuket Branch**

156/3 Phang Nga Road  
Tumchon Taratyal,  
Amphoe Muang Phuket  
Changwat Phuket 83000, Thailand

Tel : +66 (0) 7623-2906-9  
Fax : +66 (0) 7623-2909  
Operating hours:  
Mondays till Friday  
9am to 6pm

### **Hat Yai Branch**

48/106 Phadungakdee Road  
Tumchon Hatyai, Amphoe Hatyai  
Changwat Songkhla 90110, Thailand

Tel : +66 (0) 7435-4559-61  
Fax : +66 (0) 7435-4561  
Operating hours:  
Mondays till Friday  
9am to 6pm

# **D-Link<sup>®</sup>** Technical Support Setup Procedure

---

FAQ : Quick Installation for DSL-2750E

Release date : 1/04/2013

Model Support : DSL-2750E

H/W: T1

S/W:1.xx

# D-Link<sup>®</sup> Technical Support Setup Procedure

---

## WIRELESS N 300 ADSL2+ Modem Router DSL-2750E

### Step 1: Connect device

- 1.1 Connect telephone line from wall outlet to DSL-2750E directly or
- 1.2 If you wish to use internet and your telephone at the same time, please use the splitter that comes with the packaging box.


The splitter has three ports:

**LINE:** Connect to a wall phone jack (RJ-11 jack)

**Modem:** Connect to the Line interface of the router

**PHONE:** Connect to a telephone set

- 1.3 Use LAN Cable (CAT5E: RJ45) **to** connect your computer to any LAN port of DSL-2750E.



## Step 2: Login to Router

2.1 **Open** Web Browser (Internet Explorer, Firefox , Google Chrome) and enter <http://192.168.1.1> on the Address Bar.




2.2 On the login page, please enter username and password and click 'Login'.


### **Default Username and Password:**

Username: admin

Password: admin


A screenshot of the D-Link router login page. The page has an orange header with the word "LOGIN" in white. Below the header, the text "Input username and password" is displayed. There are two input fields: "Username :" with a dropdown menu showing "admin" and a red text label "default username : admin"; and "Password :" with a masked field showing "\*\*\*\*\*" and a red text label "default password : admin". Below these fields is a checkbox labeled "Remember my login info. on this computer". At the bottom center is a "Login" button.

2.3 You will be prompted with error message below if you enter the wrong username or password. Please re-login.



Step 3: On the device Setup page, please click on 'Setup Wizard' to run the step-by-step configuration wizard.

3.1 Click 'Next' to continue.





3.2 The Time Configuration option allows you to configure, update, and maintain the correct time on the internal system clock. From this section, you can enable or disable Daylight Saving and set the time zone that you are in and set the NTP (Network Time Protocol) Server. Click "Next" to proceed to next step.

**STEP 1: SET TIME AND DATE** < 2 > 3 > 4 > 5

With the time configuration function, you can configure, update, and maintain the correct time of the internal system clock. In this page, you can set the time zone that you are in and set the network time protocol (NTP) server. You can also configure daylight saving to automatically adjust the time if necessary.

**TIME SETTING**

☒ Automatically synchronize with Internet time server

Primary NTP time server:

Secondary NTP time server:

Manual setup time: 2012 Year 05 Mon 23 Day 00 Hour 06 Min 26 Sec

**TIME CONFIGURATION**

Time Zone: (GMT+07:00) Bangkok, Hanoi, Jakarta

☒ Automatically adjust clock for daylight saving changes

Daylight Saving Start: 2000 Year 04 Mon 01 Day 02 Hour 00 Min 00 Sec

Daylight Saving End: 2000 Year 09 Mon 01 Day 02 Hour 00 Min 00 Sec

### 3.3 PPPoE Configuration:

3.3.1 Please select Country: Thailand

3.3.2 ISP: Please select your Internet Service Provider (such as : 3BB , TOT , TRUE)

After you have selected your Internet Service Provider , the wizard will fill up VPI and VCI setting automatically.

3.3.3 Protocol: Select PPPoE

Please insert **your PPPoE** username and password (these parameter come from Internet Service Provider).

Enter password twice (Password and Confirm Password)

Click Next.

In the example below: Select TRUE , Insert Username : example@trueisp Password : password

**STEP 2: SETUP INTERNET CONNECTION**   3   4   5

Please select your ISP (Internet Service Provider) from the list below.

country: Thailand ▼

ISP: TRUE (Huawei) ▼

Protocol: PPPoE ▼

Encapsulation Mode: LLC ▼

VPI: 0 (0-255)

VCI: 100 (32-65535)

Search Available PVC:

---

**PPPOE PPPOA**

Please enter the user name and password provided by your Internet service provider (ISP). Note that the information is case-sensitive. Click "Next" to continue.

Username:

Password:

Confirm Password:

### 3.4 Wireless (WIFI) Setup:

3.4.1 Check the 'Enable Your Wireless Network' box.

3.4.2 Enter your preferred wireless network name (SSID).

3.4.3 Enter your wireless encryption key. If you do not want to setup Wireless Security, please Select 'None'.

Example of WPA key configuration: Select WPA2 , WPA2 Pre-Shared Key is 12345678  
Click Next.

**STEP 3: CONFIGURE WIRELESS NETWORK** - 4 - 5

The wireless network is enabled by default. You can deselect it to disable it and click "Next" to skip the configuration of wireless network.

**Enable Your Wireless Network :** ☒

For security concerns, it is highly recommended to change the pre-configured network name. Please set a name for your wireless network that can be easily recognized by wireless clients.

**Wireless Network Name (SSID) :** D-Link

If you select "Visible", the SSID of your wireless network can be found by wireless clients. If you select "Invisible", your wireless network is hidden and users need to manually enter the SSID in order to connect to your wireless network.

**Visibility Status :** ☒ Visible ☐ Invisible

In order to protect your network from hackers and unauthorized users, you are highly recommended to select one of the following wireless network security settings.

None	Security Level		Best
<input type="radio"/> None	<input type="radio"/> WEP	<input type="radio"/> WPA-PSK	<input checked="" type="radio"/> WPA2-PSK

**Security Mode:** WPA2-PSK  
Select this option if your wireless adapters support WPA2-PSK.

Please enter your wireless security key:

**WPA2 Pre-Shared Key :** ••••••••

(8-63 characters, such as a~z, A~Z, or 0~9, i.e. "%Fortress123&")

**Note:** Please enter the same key on your wireless clients to enable proper wireless connection.

Back Next Cancel

Step 4 : Change administrator password:

**Default Username and Password:**

Username: admin

Password: admin

4.1 If you do not wish to change the administrator password, please click 'Skip'

4.2 Please follow steps below if you wish to change password,

Current Password: Insert current Password (Default Password is admin)

New Password : Insert new Password

Confirm Password : Insert new Password again

Click Next.



#### STEP 4: ACCOUNT PASSWORD - 5

Use the fields below to change or create passwords. Note: Password cannot contain a space.

##### ACCOUNT PASSWORD

Username:

Current Password:  default password : admin

New Password:

Confirm Password:


#### BROADBAND

**Step 5 :** This page shows a summary of setup that you have just completed. Click Apply.

The following shows a detailed summary of your settings. Please print this page out or write the information on a piece of paper, and save it, so you can correctly configure the settings on your wireless client adapters later based on the information in this page.

Time Settings :	enable
NTP Server 1 :	ntp1.dlink.com
NTP Server 2 :	ntp.dlink.com.tw
Time :	not set!
Time Zone :	THA
Daylight Saving Time :	enable
Daylight start :	2000-04-01T02:00:00
Daylight end :	2000-09-01T02:00:00
wan_type	DSL
VPI / VCI :	0/100
Protocol :	PPPoE
Connection Type :	LLC
Username :	example@truehisp
Password :	password
Wireless Network Name (SSID) :	D-Link
Visibility Status :	visible
Encryption :	WPA2-PSK
Pre-Shared Key :	12345678
WEP Key :	not set!
New password:	admin123

**Step 6 :** The device will reboot. You may start using the device after rebooted successfully.



## Technical Support

**Call Center : 02-6617997**

**ภาษาไทย : จันทร์ ถึง ศุกร์ เวลา 9.00 น. – 18.00 น.**

**Thai : Mon – Fri : Time 9.00 – 18.00.**

**ภาษาอังกฤษ : เสาร์ , อาทิตย์ , วันหยุดนักษัตร และ วันธรรมดา หลัง 18.00 น.**

**English : Sat – Sun , Public Holiday and after 18.00 weekday.**

**Website : [www.dlink.co.th](http://www.dlink.co.th)**

**Email: [support@dlink.com.sg](mailto:support@dlink.com.sg)**

**Facebook : <http://www.facebook.com/DLinkThailandFans>**

## Nationwide D-Link Service Centres

### Chiang Mai Branch

2/1 Moo 3, Chiang Mai-Lampang Road  
Tumbon Chang Pueak, Amphoe Muang Chiang Mai  
Changwat Chiang Mai 50300,  
Thailand

Tel : +66 (0) 5340-9482-6  
Fax : +66 (0) 5340-9486  
Operating hours:  
Mondays till Friday  
9am to 6pm

### Phitsanulok Branch

117/7 Praongdam Road  
Tumbon Nai Muang,  
Amphoe Muang Phitsanulok  
Changwat Phitsanulok 65000, Thailand

Tel : +66 (0) 5521-2323-5  
Fax : +66 (0) 5521-2326  
Operating hours:  
Mondays till Friday  
9am to 6pm

### Cham Issara Tower II

3rd Floor, Cham Issara Tower II  
2922/139 New Petchburi Road  
Khwang Bangkapi, Khet Huay-Kwang,  
Bangkok 10320, Thailand

Tel : +66 (0) 2308-2040  
Fax : +66 (0) 2308-2024  
Call Center : +66 (0) 2716-6669  
Operating hours:  
Mondays till Friday  
9am to 6pm

### Pango Plaza Branch

4th Fl. Pango Plaza 604/3 Petchburi Road Room  
439-440  
Kwang Thanon Petchburi, Khet Ratchathewi  
Bangkok 10400, Thailand

Tel : +66 (0) 2656 6037  
Tel : +66 (0) 2656 6054  
Fax : +66 (0) 2656 6042  
Operating hours:  
Mondays till Sunday  
10am to 7pm

### Rayong Branch

217/24 Sukhumvit Road  
Tumbon Neen Phra,  
Amphoe Muang Rayong  
Changwat Rayong 21000, Thailand

Tel : +66 (0) 3880-0631-3  
Fax : +66 (0) 3880-0634  
Operating hours:  
Mondays till Sunday  
9am to 6pm

### Surat Thani Branch

412/8 Talat Mai Road  
Tumbon Talat,  
Amphoe Muang Surat Thani  
Changwat Surat Thani 84000, Thailand

Tel : +66 (0) 7721-7907-10  
Fax : +66 (0) 7721-7910  
Operating hours:  
Mondays till Friday  
9am to 6pm

### Phuket Branch

156/3 Phang Nga Road  
Tumbon Tarayai,  
Amphoe Muang Phuket  
Changwat Phuket 83000, Thailand

Tel : +66 (0) 7623-2906-9  
Fax : +66 (0) 7623-2909  
Operating hours:  
Mondays till Friday  
9am to 6pm

### Hat Yai Branch

48/106 Phadungakdee Road  
Tumbon Hatyai, Amphoe Hatyai  
Changwat Songkhla 90110, Thailand

Tel : +66 (0) 7435-4559-61  
Fax : +66 (0) 7435-4561  
Operating hours:  
Mondays till Friday  
9am to 6pm

Quick Installation for DSL-2750E

**D-Link**

## NOTES

# WIRELESS NETWORK REMINDER

Wireless Network Name (SSID)

Wireless Network Password