


- **Security - Disable Remote Management on router**

**Step 1:** Open your Internet browser and enter **http://dlinkrouter**, **http://dlinkrouter.local**, or **http://192.168.0.1** into the address bar.



**Step 2:** Enter your login information in the fields provided. The default username is Admin. Enter your administrator password. If you have not changed the default password, leave this field blank. Click Login.

A screenshot of the D-Link router's login page. At the top is an orange banner with the "D-Link" logo. Below this is a "LOGIN" section with a light gray background. It contains the text "Login to the router :", followed by two input fields: "User Name : Admin" and "Password : ". To the right of the password field is a "Login" button. At the bottom of the page is a dark gray banner with the word "WIRELESS" in white capital letters.

**Step 3:** Click on the **TOOLS** tab and navigate down to the **ADMINISTRATION** section.


	SETUP	ADVANCED	TOOLS	STATUS	SUPPORT
ADMIN	ADMINISTRATOR SETTINGS				Helpful Hints...

## Disable Remote Management:

**Step 4:** Uncheck the box to **Disable Remote Management**.

**Step 5:** Remove **Remote Admin Port** dialogue box.

- Click **Save Settings**

ADMIN	<b>ADMINISTRATOR SETTINGS</b> The 'admin' account can access the management interface. The admin has read/write access and can change password. By default there is no password configured. It is highly recommended that you create a password to keep your router secure. <input type="button" value="Save Settings"/> <input type="button" value="Don't Save Settings"/>	<b>Helpful Hints...</b> <ul style="list-style-type: none"><li>• For security reasons, it is recommended that you change the password for the Admin account. Be sure to write down the new password to avoid having to reset the router in case they are forgotten.</li><li>• When enabling Remote Management, you can specify the IP address of the computer on the Internet that you want to have access to your router, or leave it blank to allow access to any computer on the Internet.</li><li>• Select a filter that controls access as needed for this admin port. If you do not see the filter you need in the list of filters, go to the <b>Advanced -&gt; Inbound Filter</b> screen and create a new filter.</li><li>• <b>More...</b></li></ul>
TIME	<b>ADMIN PASSWORD</b> Please enter the same password into both boxes, for confirmation. Password : <input type="password"/> Verify Password : <input type="password"/>	
SYSLOG	<b>SYSTEM NAME</b> Gateway Name : <input type="text" value="DIR-868L"/>	
EMAIL SETTINGS	<b>ADMINISTRATION</b> Enable Graphical : <input type="checkbox"/> Authentication Enable HTTPS Server : <input checked="" type="checkbox"/> Enable Remote Management : <input type="checkbox"/>  Remote Admin Port : <input type="text" value="8080"/> Use HTTPS: <input type="checkbox"/> Remote Admin <a href="#">Inbound Filter</a> : <input type="text" value="Allow All"/> Details : <input type="text" value="Allow All"/> <input type="button" value="Save Settings"/> <input type="button" value="Don't Save Settings"/>	
SYSTEM		
FIRMWARE		
DYNAMIC DNS		
SYSTEM CHECK		
SCHEDULES		